

Roller Spindle Fitting Instructions For Cardale Mk2

1. Lock the tension on the spring drum unit. This is done by pulling on the cables until the holes in the centre part of the spring unit line up with the holes in the outer bracket. Then insert a 6" pin or nail through the holes and slowly release the cables
2. Take the bottom screw out of the track, push the track over and remove and replace the wheel spindle
3. Replace the screw in the bottom of the track making sure the loop on the end of the cable is over the spindle
4. Make sure the other end of the cable is securely fitted into the spring unit. Pull the cables and remove the pin, letting the cables back slowly and making sure they are in the two grooves around the pulley

All work is undertaken at your own risk.

SKU: CAS4010