

## How to programme your new hand transmitter to your Duo:



1. Find the control box (picture A).



2. Remove the white cover (picture B)



3. Cover removed (picture C)



4. Take a small screwdriver press the button as shown in picture D once and release

5. A red light starts to shine (picture D ★)



6. Take the handset. Hold the first button down. The red light in picture D starts to flash. (picture E ★)

7. Hold down the button on the handset until the red light stops flashing and goes out (picture E)

**The handset is programmed and ready for use! Other buttons on your hand transmitter can also be programmed by repeating this procedure.**

