


Part No's. P9900004
S9900004-3
S9900004-2

How to fit a new Cable to Your Garador


Description: Spring Cable Assembly
Models: Garador S/S, MK3, MK3C, Welvent, MK3c(V), C Type (Plastic cover spring unit models only), Belgavia.

Fitting Instructions


1. Remove plastic cover from the spring unit box by sliding to one side. Remove any pieces of broken cable.



2. (a) insert one end of the new cable over the pulley wheel mounted in the link arm bracket. Place a stout screw driver through the eye of the cable, as shown. (b) Thread the other end of the cable downwards and around the pulley wheel at the end of the spring. Finally, fasten eye over the hook mounted on the spring box. N.B This last operation begins the tensioning of the spring.




3. Replace plastic cover sliding it to a central position.
4. Pull cable downwards until the spring retaining bracket can be located in the socket at the back of the spring unit.




NB. Some assistance may

N.B Some assistance may be required to complete this instruction.

5. Pass free end of cable downward inside guide channel behind link arm. Finally, attach eye at end of the cable to hook on the spindle roller.



6. Take up slack wire by pulling cable across the door in the direction of the arrow. Ensure that the cable is snugly bedded in the grooves of both pulley wheels. Pull the cable until the retaining bracket at the end of the spring is released from its socket.



It is recommended that a piece of cloth is used between cable and handle. Some assistance

may be required using the free hand to lightly pull the retaining bracket clear of its socket should it not completely release. When the retaining bracket has released, allow the spring to gently take

Warning – It is important that this instruction is followed correctly as damage to cable or loss of pre-tension could occur.

5. Lubricate inside of guide channels, cable latch and all other moving parts. To ensure continued ease of operation lubricate periodically.

GARADOR

Bunford Lane, Yeovil, Somerset, BA20 2YA
Tel: 01935 443722 Fax: 01935 443744