

WARNING

ONLY INSTALL THIS UNIT ON AUTOMATIC GARAGE DOOR OPERATORS THAT ARE UL 325 APPROVED OR EQUIVALENT

- DOOR MUST HAVE A PRIMARY AND SECONDARY MEANS TO SENSE AND REACT (REVERSE) TO OBSTRUCTIONS WITHIN 2 SECONDS.
- EXAMPLE: YOUR GARAGE DOOR MUST REVERSE WITHIN 2 SECONDS IF REASONABLE PRESSURE IS PLACED ON BOTTOM EDGE OF DOOR WHEN CLOSING (PRESSURE REVERSING SENSOR) AND THE DOOR MUST HAVE A CONTACT SENSOR THAT WILL REVERSE DOOR IF BROKEN (PHOTO EYE BEAM ACROSS DOOR FLOOR.)

DO NOT INSTALL THIS UNIT IF YOU DO NOT HAVE PHOTO EYE BEAM OR SIMILAR SAFETY SYSTEM ON GARAGE DOOR OPERATOR.

THIS UNIT IS TO BE USED AS A SECURITY DEVICE TO ENSURE CLOSURE OF GARAGE DOOR. IT IS NOT INTENDED TO BE USED AS THE PRIMARY

· 1 ·

MEANS OF CLOSING THE GARAGE DOOR. FOR SAFETY REASONS IT IS RECOMMENDED THAT THE USER KEEP THE DOOR IN SIGHT WHEN CLOSING. MIND EASE SHOULD ONLY BE USED AS A BACK-UP.

THIS UNIT WILL NOT INTERFERE WITH EXISTING GARAGE DOOR OPERATOR SAFETY FEATURES.

DO NOT LEAVE CHILDREN OR PETS UNATTENDED IN OR AROUND THE GARAGE.

This unit can not be used on its own. It is an ADD ON for consumers who already have an Automatic Garage Door Opener.

This unit will only work when garage door is completely open.

IF VEHICLE IS LEFT RUNNING IN GARAGE MAKE SURE DOOR IS FULLY OPEN AND TIMER IS SET FOR APPROPRIATE AMOUNT OF TIME OR TURN THE UNIT OFF.

· 2 ·

THIS PRODUCT RUNS OFF CLASS 2 POWER CIRCUIT & is **Patent Pending**

*Door and operator must be installed according to manufactures guidelines.

*Test safety features once a month according to manufactures guidelines.

Mind Ease List:

1. Timer Relay Unit
2. 12 " Wire (white tip)
3. Mounting Hardware/screws/nuts
4. Garage Door Magnetic Micro-Switch
5. 40' foot Wire (black tip)
6. Metal Angle Mounting Bracket
7. Magnetic Sensor

This product runs off Class 2 Power Circuit.

For more info please visit our website at www.garagedoorsecurity.com


USER GUIDE AND MOUNTING INSTRUCTIONS FOR MINDEASE GARAGE DOOR SYSTEMS LTD.

1. Before mounting the timer relay unit you must install the 9 volt battery. Remove the back of the unit by removing a single Phillips (*) screw near the bottom of the unit. Put battery in and place in space provided. Replace back of unit. Make sure the on/off switch is in the off position.
2. Attach mounting bracket on wall using 2 enclosed 1" screws and plastic plugs. If using plastic plugs first drill pilot holes using 1/4" drill bit. Mounting hooks should be facing away from the wall, side with 2 hooks should be pointing up. Be sure to mount close enough to your existing garage door button for the 12" wire to connect to the Mind Ease Timer Relay Unit and your garage door button.
3. Place Mind Ease unit on wall mount. Remove the face of your existing garage door button. Plug 12" white wire into the white plug (on right) of top of Mind Ease unit. Attach the other end of wire (exposed) to the 2 wire terminals on your existing garage door button. It does **not** matter which wire you place on the terminal as long as each of the 2 wires is on separate terminals.

4. Replace garage door button face.
5. Attach metal angle bracket to end of garage door rail using nuts & bolts provided. Do not mount bracket in areas that will interfere with operation (movement) of garage door. This step may require 2 holes to be drilled in the rail to securely mount the angle bracket. This will allow you to adjust the bracket to match up to the magnetic sensor. **See diagram #1a & #1b.**
6. Attach the magnetic sensor with the 2 connection terminals to the metal angle bracket with dual sided adhesive tape. Sensor should be facing garage door. **See diagram #2.**
7. Open garage door fully. Attach other half of magnetic sensor to the lip of the garage door so that it lines up with the magnetic sensor attached to the angle bracket. Attach magnetic sensor with adhesive tape or if possible with screws provided.

SECTIONAL GARAGE DOOR EXAMPLE MOUNTING INSTRUCTIONS


Diagram 1a



NOTE
ANGLE BRACKET CAN BE EASILY BENT TO LINE
UP MAGNETIC SENSORS

ONE-PIECE DOOR EXAMPLE MOUNTING INSTRUCTIONS

Diagram 1b




WIRE FROM MIND EASE UNIT
CONNECT TO MAGNETIC
SENSOR ON ANGLE BRACKET

NOTE

OPEN GARAGE DOOR WHEN LINEING UP MAGNETIC SENSORS.
WHEN DOOR IS CLOSED MAGNETIC SENSORS SHOULD NOT LINE UP

Diagram
2



*NOTE

IT DOES NOT MATTER WHICH FORK IS
PLACED ON THE SCREWS AS LONG AS
THEY ARE ON SEPERATE SCREWS

8. Adjust angle bracket to leave a 1/4" gap between the 2 magnetic sensors. Tighten nuts.
9. Plug the black 40' wire into the black plug on top left of the Mind Ease Unit. Run wire up wall or along top of roof using wire clips provided. Attach end of wire (forked end) to magnetic sensor on angle bracket. Again it does **not** matter which wire is placed on either terminals as long as they are on separate terminals.

10. The Mind Ease Unit is now fully installed.

11. Close the garage door, set the time for 5 minutes & turn the unit on. Fully open the garage door. Wait and watch the unit "activate". There will be a 20 sec. audio warning prior to door closing. Installer must check garage door safety features to make sure they are working properly. eg; when unit activates if photo eye beam is broken the door should automatically reverse.

Door must be in closed position when setting the timer. If timer is adjusted when door is open it will default to original time set.

***Note:**

Power On Battery Check

If voltage drops less than 7.2V, beeper will beep every 1.5 seconds for 30 seconds. Unit will still be functional, this indicates it is time to change the battery.